User Manual



Offset Cantilever Umbrella Product Code:R3-330-C



If you are satisfied with this product, please let us know. If you have questions, we're always here to help! You know the strenght of social media nowadays and we would appreciate a positive review on the website of your purchase. We appreciate the time you have taken and will actively use it to improve our products and service to you.

Please, visit our website www.sorara.eu for more information about our products and where you can purchase them.

Email: info@sorara.eu




Web: www.sorara.eu



Umbrella supplied is fully assembled. Please read instructions prior installation.

Take all parts out of the box. If any parts are missing, please do not return to the place of purchase directly. Please email us first info@sorara.eu

REF	NB	
A	1PC	
В	1PC	
C	1PC	
D	1PC	10
E	1PC	
F	2PCS	
G	6PCS	
Н	1PC	
I	1PC	
J	1PC	
K	9PCS	T) MOCCOCCU-



Step1. Place the upper cross leg (C) over the lower cross leg (D) to form a'+'.




Step2. Place the tube (B) onto the cross base with bolt (G), tighten the bolt with part (I).




Step3. Insert the pole (E) onto the base pole (B). Pay attention to screw hole position.



Step4. Place part (H) on the pole (E).



Step5. Insert the pole (A) onto the assembled cross base. Pay attention to screw hole position. Block part (A) and part (B) with the bolt (G). Cover the cap (F) on the bolt (G).



Step6. Insert the handle (J) into the hole of winch to open the umbrella



Option: If the unbrella is used on the wooden deck, tighten the screws (K) with the base and the deck to keep the umbrella stable.

Caution: Please keep the base stable when open the umbrella. To keep your umbrella open with safety, we strongly suggest to purchase our triangle plastic base together. Please search for "8719189103700" on Amazon.